

nanoKEY

MIDI Implementation Chart

Function		Transmitted	Recognized	Remarks
Basic Channel	Default	1 – 16	×	Memorized
	Changed	1 – 16	×	
Mode	Memorized Messages Altered	×	×	*1
		○ *****	×	
Note Number:	True Voice	0 – 127 *****	×	
Velocity	Note On Note Off	○ 1 – 127 ○ 64	×	
Aftertouch	Polyphonic (Key) Monophonic (Channel)	×	×	
		×	×	
Pitch Bend		○	×	[PITCH] button
	0 – 127	○	×	Keyboard (CC Mode), [MOD] button
Control Change				
Program Change	Variable Range	×	×	
		*****	*****	
System Exclusive		○	○	*2
System Common	Song Position Song Select Tune	×	×	
		×	×	
		×	×	
System Real Time	Clock Command	×	×	*1 *1
Aux Messages	Local On/Off All Notes Off Active Sense Reset	○ ○ ×	×	
		×	×	
Notes				
*1: Valid if assigned as a MIDI control change.				
*2: In addition to Korg exclusive messages, also responds to inquiry messages.				

Mode 1: OMNI ON, POLY
Mode 3: OMNI OFF, POLY

Mode 2: OMNI ON, MONO
Mode 4: OMNI OFF, MONO

○ : Yes
× : No

Consult your local Korg distributor for more information on MIDI IMPLEMENTATION.
MIDI Implementationの配布については、コルグお客様相談窓口へお問い合わせください。