

FW-1082 Default MIDI Programming Set-up

Control	Bank	Action	#	Channel	Ports
EQ/PAN	All	Note On/Off	1	1	1
HIGH	All	Note On/Off	28	1	1
HI-MID	All	Note On/Off	29	1	1
LOW	All	Note On/Off	30	1	1
LOW-MID	All	Note On/Off	31	1	1
F1	All	Note On/Off	32	1	1
F2	All	Note On/Off	33	1	1
F3	All	Note On/Off	34	1	1
F4	All	Note On/Off	35	1	1
UP ARROW	All	Note On/Off	0	1	None
LEFT ARROW	All	Note On/Off	0	1	None
RIGHT ARROW	All	Note On/Off	0	1	None
DOWN ARROW	All	Note On/Off	0	1	None
SHTL	All	Note On/Off	0	1	None
<LOCATE	All	Note On/Off	0	1	None
LOCATE>	All	Note On/Off	0	1	None
SET	All	Note On/Off	0	1	None
IN	All	Note On/Off	0	1	None
OUT	All	Note On/Off	0	1	None
REW	All	Note On/Off	0	1	None
F FWD	All	Note On/Off	0	1	None
STOP	All	Note On/Off	0	1	None
PLAY	All	Note On/Off	0	1	None
RECORD	All	Note On/Off	0	1	None
FOOTSWITCH	All	Note On/Off	0	1	None
MUTE1	1	Note On/Off	48	1	1
MUTE2	1	Note On/Off	49	1	1
MUTE3	1	Note On/Off	50	1	1
MUTE4	1	Note On/Off	51	1	1
MUTE5	1	Note On/Off	52	1	1
MUTE6	1	Note On/Off	53	1	1
MUTE7	1	Note On/Off	54	1	1
MUTE8	1	Note On/Off	55	1	1

Control	Bank	Action	#	Channel	Ports
SOLO1	1	Note On/Off	56	1	1
SOLO2	1	Note On/Off	57	1	1
SOLO3	1	Note On/Off	58	1	1
SOLO4	1	Note On/Off	59	1	1
SOLO5	1	Note On/Off	60	1	1
SOLO6	1	Note On/Off	61	1	1
SOLO7	1	Note On/Off	62	1	1
SOLO8	1	Note On/Off	63	1	1
SEL1	1	Note On/Off	64	1	1
SEL2	1	Note On/Off	65	1	1
SEL3	1	Note On/Off	66	1	1
SEL4	1	Note On/Off	67	1	1
SEL5	1	Note On/Off	68	1	1
SEL6	1	Note On/Off	69	1	1
SEL7	1	Note On/Off	70	1	1
SEL8	1	Note On/Off	71	1	1
MUTE1	2	Note On/Off	48	1	2
MUTE2	2	Note On/Off	49	1	2
MUTE3	2	Note On/Off	50	1	2
MUTE4	2	Note On/Off	51	1	2
MUTE5	2	Note On/Off	52	1	2
MUTE6	2	Note On/Off	53	1	2
MUTE7	2	Note On/Off	54	1	2
MUTE8	2	Note On/Off	55	1	2
SOLO1	2	Note On/Off	56	1	2
SOLO2	2	Note On/Off	57	1	2
SOLO3	2	Note On/Off	58	1	2
SOLO4	2	Note On/Off	59	1	2
SOLO5	2	Note On/Off	60	1	2
SOLO6	2	Note On/Off	61	1	2
SOLO7	2	Note On/Off	62	1	2
SOLO8	2	Note On/Off	63	1	2
SEL1	2	Note On/Off	64	1	2
SEL2	2	Note On/Off	65	1	2
SEL3	2	Note On/Off	66	1	2
SEL4	2	Note On/Off	67	1	2
SEL5	2	Note On/Off	68	1	2
SEL6	2	Note On/Off	69	1	2
SEL7	2	Note On/Off	70	1	2
SEL8	2	Note On/Off	71	1	2

Control	Bank	Action	#	Channel	Ports
MUTE1	3	Note On/Off	48	1	None
MUTE2	3	Note On/Off	49	1	None
MUTE3	3	Note On/Off	50	1	None
MUTE4	3	Note On/Off	51	1	None
MUTE5	3	Note On/Off	52	1	None
MUTE6	3	Note On/Off	53	1	None
MUTE7	3	Note On/Off	54	1	None
MUTE8	3	Note On/Off	55	1	None
SOLO1	3	Note On/Off	56	1	None
SOLO2	3	Note On/Off	57	1	None
SOLO3	3	Note On/Off	58	1	None
SOLO4	3	Note On/Off	59	1	None
SOLO5	3	Note On/Off	60	1	None
SOLO6	3	Note On/Off	61	1	None
SOLO7	3	Note On/Off	62	1	None
SOLO8	3	Note On/Off	63	1	None
SEL1	3	Note On/Off	64	1	None
SEL2	3	Note On/Off	65	1	None
SEL3	3	Note On/Off	66	1	None
SEL4	3	Note On/Off	67	1	None
SEL5	3	Note On/Off	68	1	None
SEL6	3	Note On/Off	69	1	None
SEL7	3	Note On/Off	70	1	None
SEL8	3	Note On/Off	71	1	None
MUTE1	4	Note On/Off	48	1	None
MUTE2	4	Note On/Off	49	1	None
MUTE3	4	Note On/Off	50	1	None
MUTE4	4	Note On/Off	51	1	None
MUTE5	4	Note On/Off	52	1	None
MUTE6	4	Note On/Off	53	1	None
MUTE7	4	Note On/Off	54	1	None
MUTE8	4	Note On/Off	55	1	None

Control	Bank	Action	#	Channel	Ports
SOLO1	4	Note On/Off	56	1	None
SOLO2	4	Note On/Off	57	1	None
SOLO3	4	Note On/Off	58	1	None
SOLO4	4	Note On/Off	59	1	None
SOLO5	4	Note On/Off	60	1	None
SOLO6	4	Note On/Off	61	1	None
SOLO7	4	Note On/Off	62	1	None
SOLO8	4	Note On/Off	63	1	None
SEL1	4	Note On/Off	64	1	None
SEL2	4	Note On/Off	65	1	None
SEL3	4	Note On/Off	66	1	None
SEL4	4	Note On/Off	67	1	None
SEL5	4	Note On/Off	68	1	None
SEL6	4	Note On/Off	69	1	None
SEL7	4	Note On/Off	70	1	None
SEL8	4	Note On/Off	71	1	None
GAIN ENCODER	All	Controller	48	1	1
FREQ ENCODER	All	Controller	49	1	1
Q ENCODER	All	Controller	50	1	1
DATA WHEEL	All	Controller	0	1	None
PAN	1	Controller	40	1	1
PAN	2	Controller	40	1	2
PAN	3	Controller	40	1	3
PAN	4	Controller	40	1	4
MASTER FADER	All	Controller	7	1	None
FADER 1	1	Controller	32	1	1
FADER 2	1	Controller	33	1	1
FADER 3	1	Controller	34	1	1
FADER 4	1	Controller	35	1	1
FADER 5	1	Controller	36	1	1
FADER 6	1	Controller	37	1	1
FADER 7	1	Controller	38	1	1
FADER 8	1	Controller	39	1	1

Control	Bank	Action	#	Channel	Ports
FADER 1	2	Controller	32	1	2
FADER 2	2	Controller	33	1	2
FADER 3	2	Controller	34	1	2
FADER 4	2	Controller	35	1	2
FADER 5	2	Controller	36	1	2
FADER 6	2	Controller	37	1	2
FADER 7	2	Controller	38	1	2
FADER 8	2	Controller	39	1	2
FADER 1	3	Controller	32	1	None
FADER 2	3	Controller	33	1	None
FADER 3	3	Controller	34	1	None
FADER 4	3	Controller	35	1	None
FADER 5	3	Controller	36	1	None
FADER 6	3	Controller	37	1	None
FADER 7	3	Controller	38	1	None
FADER 8	3	Controller	39	1	None
FADER 1	4	Controller	32	1	None
FADER 2	4	Controller	33	1	None
FADER 3	4	Controller	34	1	None
FADER 4	4	Controller	35	1	None
FADER 5	4	Controller	36	1	None
FADER 6	4	Controller	37	1	None
FADER 7	4	Controller	38	1	None
FADER 8	4	Controller	39	1	None