

## New MEMORY REC function added in Ver 1.60


Even if no SD card is available, it is now possible to record for up to 35 seconds using the built-in memory. This is useful for spoken notes and other brief recordings.

### Caution

- Only one recorded file with a maximum length of 35 seconds can be saved in the built-in memory. Be aware that for this reason the previous recording will be overwritten by each new recording.
- This function can only be used in stereo mode.

## Changing the recording mode


1. Press the [MENU] button and select <TOOL> on the MENU screen.



2. Select <MEMORY REC> on the TOOL screen.



3. Select <REC&PLAY> on the BLT-IN MEMORY REC screen to change to the MEMORY REC mode.



## Using built-in memory for recording and playback

Recording and playback operations are the same as when using an SD card. See the OPERATION MANUAL for details.

- NOTE** • The only recording format that can be used is 96kbps MP3.

## Transferring the recording to an SD card

1. Select <BACK-UP> on the BLT-IN MEMORY REC screen.



2. Select <NAME> if you want to change the file name or <FOLDER> if you want to change the destination folder.



- NOTE** • The destination folder will be a stereo mode folder.

3. Select <EXECUTE> after setting the NAME and FOLDER.



### NOTE

- If a file with the same name already exists in the destination folder, a screen appears where you can choose to either rename the file being transferred or cancel the operation.



4. When a confirmation screen appears, select <YES> to transfer the file to the SD card and erase it from the built-in memory.

